

JAUNA NOITAIJATZNI





Before installation.



Pry the right air-condition outlet with crow plate as shown in the picture.



Pry the left air-condition outlet with crow plate as shown in the picture.



Remove the four screws used for fixing air-condition.



Pry the decorative plate in the console with Remove the four screws used for fixing crow plate and pull out the socket of hazard the original radio. light under the decorative plate.





Unplug the wire that connects the original radio and car and remove the original radio.

Put the two USB cables in the glove box an connect all the back wires of head unit to



the car.



Put the two USB cables in the glove box and Install the head unit and tighten the screws.



Installation finished.